



4. Chariots et accessoires | Kreuzsupporte und Zubehör | Carriages and accessories



0070-45000-000



0070-47000-000



0070-46090-000

0070-45000-000 Chariot à vis (fait partie de la machine de base)
Kurbel-Kreuzsupport (gehört zu Grundausstattung der Maschine)
 Screw-operated carriage (included in the basic machine)

0070-47000-000 Chariot à leviers
Hebel-Kreuzsupport
 Lever-operated carriage

0070-46090-000 Support arrière réglable longitudinalement et transversalement
Hinterer Stahlhalteruntersatz längs und quer verstellbar
 Rear Support adjustable longitudinally and transversely